


Control backup con protección de sobretensión
Backup control with overvoltage protection
Commande backup avec protection contre le surtension





Terminales Backup del inversor Backup inverter terminals Terminaux backup de l'onduleur		
INVERSOR INVERTER ONDULEUR	A	B
HUAWEI SUN2000-(2KTL...6KTL)-L1 SUN2000-(8K...10K)-LC0 SUN2000-(3K...6K)-LB0	5 GND	8 DI2 
KOSTAL PLENTICORE MP G3 (Necesita resistencia de 6,8 kΩ) (Requires a 6.8 kΩ resistor) (Nécessite une résistance de 6,8 kΩ)	GND	In1
GROWATT MIN-(2500...6000)-TL-XH	8	3
SIGENERGY SIGEN Hybrid (2.0...6.0) SP2	GND	D1